

LACUNZA WOOD BOX 800/1000

Assembly Instructions

1. Place the bottom panel on a flat, stable surface.
2. Attach the left or right side panel to the bottom panel using the provided screws. Repeat for the opposite side.
3. Position the top panel and secure it with screws.
4. Install the back panel and fasten it in place.

Assembly is now complete.

